


SET UP GUIDE FOR ARCH FLAG - 2,4 m & 3,2 m height.




Watch set-up video for easy assembling

Use link or QR-code:
<https://bannerbow.com/videos/>



Note:
 Outdoor use requires using Guy Ropes and anchors.

CONTENT

-  10 Kg (45x45 cm) 2x
-  5 Kg (Ø35 cm) 2x
-  1x Small (2,4m)
-  1x Large (3,2m)
-  8x
-  8x
-  8x
-  2x
-  4x
-  4x
-  4x

Packaged by:

BANNERBOW®
 DESIGNING PORTABLE SPACE

CONTACT INFORMATION
 info@bannerbow.com
 www.bannerbow.com

Address:
 Rinmangatan18
 633 46 Eskilstuna
 Sweden



COPYRIGHT BANNERBOW®